

Manual, Assembly instruction: Brodit 852920

Center mount

1.)



2.)



3.)



4.)



Attention! Read all instructions before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the dashboard and the frame surrounding the control panel to widen the gap. Peel off adhesive tape covers on the ProClip.

2. Hook the upper part of the ProClip into the gap next to the gap opener. Pull out the gap opener.

3. Press the gap opener into the gap between the stereo and the surrounding frame. Press the lower part of the ProClip into the gap next to the gap opener. Pull out the gap opener.

4. The ProClip is in place.