

Manual, Assembly instruction: Brodit 852932

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip. NOTE: It is very important to place the ProClip in the exact same position as shown in the pictures.

- 1.** Press the upper part of the ProClip into the gap between the dashboard and the panel surrounding the control panel. Press until you hear or see/feel it snap into place.
- 2.** Press the lower part of the ProClip into the gap between the panel surrounding the air vents and the frame surrounding the control panel. Press until you hear or see/feel it snap into place.
- 3.** The ProClip is in place.
- 4.** The ProClip is in place.