

Manual, Assembly instruction: Brodit 852934

Center mount

1.)



2.)



3.)



4.)



Attention! Read all instructions before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the air vents and the control panel. Peel off the cover of the adhesive tape on the ProClip. Press forward/downward on the gap opener so the gap widens. Press the grooved lower part of the ProClip into the gap next to the gap opener.

2. Pull out the gap opener. Slide the ProClip towards the steering wheel.

3. Press forward on the ProClip so the angled edge of the upper part of the ProClip snaps over the edge of the frame surrounding the air vents.

4. The ProClip is in place.