

Manual, Assembly instruction: Brodit 852935

Angled mount



Attention! Read all instructions before attaching the ProClip.

1. Open the glove compartment. Press the thin end of the enclosed gap opener into the gap between the control panel and the dashboard by the lower part of the stereo, to widen the gap. Peel off the adhesive tape covers on the ProClip.
2. Press the short left part of the ProClip into the gap above the gap opener. Pull out the gap opener.
3. Press the gap opener into the gap between the glove compartment and the dashboard. Press forward on the ProClip so the angled right part of the ProClip goes into the gap above the gap opener. Pull out the gap opener. Close the glove compartment.
4. The ProClip is in place.