

## Manual, Assembly instruction: Brodit 852936

Center mount

1.)



2.)



3.)



4.)



**Attention! Read all instructions before attaching the ProClip.** Peel off the adhesive tape covers on the ProClip.

1. Press the angled lower part of the ProClip into the gap between the frame surrounding the air vent and the surrounding panel.
2. Press upwards on the dashboards overhang. Place the upper part of the ProClip into the gap under the dashboard overhang.
3. Press downwards on top of the dashboard.
4. The ProClip is in place.