

Manual, Assembly instruction: Brodit 852939

Center mount

1.)



2.)



3.)



4.)



Attention! Read all instructions before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the dashboard and the frame surrounding the control panel to widen the gap. Peel off the adhesive tape covers. Place the long upper part of the ProClip under the dashboard overhang above the air vents. Press upwards on the ProClip so the adhesive tape attaches.
2. Hook the angled lower part of the ProClip into the gap next to the gap opener.
3. Pull out the gap opener. Make sure that the ProClip is properly attached.
4. The ProClip is in place.