

Manual, Assembly instruction: Brodit 852945

Angled mount



Attention! Read all instructions before attaching the ProClip.

1. Open the glove compartment. Peel off the cover of the adhesive tape on the ProClip. Press the angled edge of the long right part of the ProClip into the gap between the dashboard and the glove compartment.

2. Pull the left part of the ProClip leftwards, towards the steering wheel, so the angled edge of the right part hooks behind the glove compartment.

3. Press the left part of the ProClip, with groove, into the gap between the dashboard and the frame surrounding the control panel. Press until you hear or see/feel it snap into place.

4. The ProClip is in place.