

Manual, Assembly instruction: Brodit 852947

Center mount

1.)



2.)



3.)



4.)



Attention! Read all instructions before attaching the ProClip.

1. Peel off the adhesive tape covers on the ProClip. Press the angled edge of the lower part of the ProClip into the gap between the control panel and the dashboard surrounding the air vents.
2. Hook the angled upper part of the ProClip over the edge of the dashboard surrounding the air vents.
3. Press downwards on the upper part of the ProClip so the adhesive tape attaches.
4. The ProClip is in place.