

Manual, Assembly instruction: Brodit 852949

Center mount

1.)



2.)



3.)



4.)



Attention! Read all instructions before attaching the ProClip.

1. Peel off the adhesive tape covers on the ProClip. Press the lower part of the ProClip into the gap between the dashboard and the frame surrounding the control panel.
2. Press the upper part of the ProClip into the gap between the dashboard and the frame surrounding the air vents.
3. The ProClip is in place.
4. The ProClip is in place.