

Manual, Assembly instruction: Brodit 852950

Angled mount



Attention! Read all instructions before attaching the ProClip.

1. Peel off the adhesive tape covers on the ProClip. Place the left part of the ProClip over the gap between the climat control and the surrounding frame.
2. Press the long right part of the ProClip into the gap between the dashboard and the frame surrounding the control panel.
3. Press the left part of the ProClip into the gap between the climat control and the surrounding frame.
4. The ProClip is in place.