

Manual, Assembly instruction: Brodit 852956

Angled mount



Attention! Read all instructions before attaching the ProClip. Peel off the cover of the adhesive tape on the ProClip.

1. Press the curved edge on the left side of the ProClip into the gap between the climate control panel and the padded center console edge.

2. Press forward on the right side of the ProClip so the curved edge on the left side hooks behind the climate control panel and the angled edge on the right side of the ProClip snaps into the gap between the center console edge and the center console side wall.

3. If the angled edge doesn't snap in to the gap, press on it until it goes into the gap.

4. The ProClip is in place.