

Manual, Assembly instruction: Brodit 852957

Angled mount

1.)



2.)



3.)



4.)



Attention! Read all instructions before attaching the ProClip Part 1: The attaching part (the smallest part)
Part 2: The ProClip faceplate

1. Peel off the cover of the adhesive tape on Part 1 and place the thin angled edge into the gap between the center dashboard panel frame (next to the climate control) and the padded dashboard. Press the angled edge firmly into the gap and bend Part 1 to the right until you hear/feel it snaps into place.

2. Then press hard on Part 1, towards the dashboard, until you hear/feel it snaps behind the panel frame. (This could sound like a second snap in the panel depending of how hard you pressed the first time)

3. Press a screwdriver (Philips) firmly through the predrilled holes in Part 2 to open them up. Peel off the cover of the adhesive tape on Part 2. Place Part 2 onto Part 1 so the holes match and the adhesive tape on Part 2 is on the left side attaching to the center dashboard panel. Screw Part 2 onto Part 1 using the enclosed screws. **NOTE: DONT SCREW THE SCREWS INTO PART1 IN AN ANGLED POSITION BASED ON THE ANGLE OF PART 2, BUT STRAIGHT INTO PART 1.**

4. The ProClip is in place.