

Manual, Assembly instruction: Brodit 852969

Center mount

1.)



2.)



3.)



4.)



Attention! Read all instructions before attaching the ProClip. This ProClip consists of two parts. Part 1. Attaching part (the smallest part) Part 2. ProClip face plate

1. Peel off the cover of the adhesive tape on Part 1. Press the angled edge of Part 1 into the gap between the dashboard and the frame surrounding the air vent. Press forwards/to the left on Part 1 so it goes all the way into the gap and the adhesive tape attaches.

2. Peel off the cover of the adhesive tape on Part 2. Press the upper part of Part 2 into the gap between the dashboard and the panel surrounding the air vent/the dashboard surrounding the instrument panel.

3. Adjust Part 1 so the holes match the holes in Part 2. Screw Part 2 onto Part 1 using the enclosed screws. Note! Screw the screws straight into Part 1, in the same angle as Part 1.

4. The ProClip is in place.