

Manual, Assembly instruction: Brodit 852977

Center mount



Attention! Read all instructions before attaching the ProClip. Peel off the cover on the adhesive tape on the ProClip.

1. Place the ProClip over the air vent panel.

2. Press firmly forward on the lower part of the ProClip so the grooved edge goes into the gap between the air vent and the padded dashboard. Press firmly/hard until you see or hear/feel it snap into place.

3. Press firmly forward on the upper part of the ProClip so the angled edge goes into the gap between the air vent panel and the padded dashboard. Press firmly/hard until you see or hear/feel it snap into place.

4. The ProClip is in place.