

Manual, Assembly instruction: Brodit 852982

Center mount, Right

1.)



2.)



3.)



4.)



Attention! Read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the grooved edge on the lower part of the ProClip into the gap between the air vent panel frame and the padded part of the dashboard. Press until you see or hear/feel it snaps into place.
2. Push the upper part of the ProClip forward, towards the air vent.
3. Press firmly forward on the upper part of the ProClip so the grooved edge goes into the gap between the dashboard and the air vent panel frame, and hooks over the edge on the air vent panel frame. Press until you see or hear/feel it snaps into place.
4. The ProClip is in place.