

Manual, Assembly instruction: Brodit 853007

Angled mount

1.)



2.)



3.)



4.)



Attention! Read all instructions before attaching the ProClip. This ProClip consists of two part. Part 1. The attaching piece (the smallest part) Part 2. ProClip face plate.

1. Press the thin end of the enclosed gap opener into the gap between the control panel and the dashboard to widen the gap. Peel off the cover of the adhesive tape on Part 1. Press the angled edge of Part 1 into the gap above the gap opener.

2. Press to the right on Part 1, away from the steering wheel, so the angled edge hooks behind the control panel and the adhesive tape attaches on the dashboard.

3. Open up the predrilled holes in Part 2 with a screw driver (Philips). Peel off the cover of the adhesive tape on Part 2. Place Part 2 over Part 1 so the adhesive tape is to the left and the holes match. Screw Part 2 onto Part 1 by using the enclosed screws.

4. The ProClip is in place.