

Manual, Assembly instruction: Brodit 853013

Angled mount



Attention! Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Open the glove compartment door. Peel off the cover of the adhesive tape on the ProClip. Hook the angled edge on the right side of the ProClip over the center console edge.
2. Place your hand on the right side of the ProClip face plate and press firmly left wards, towards the steering wheel, so it hooks over the console edge.
3. Press firmly forward on the ProClip so the adhesive attaches properly. Close the glove compartment door.
4. The ProClip in place.