

## Manual, Assembly instruction: Brodit 853014

Center mount

1.)



2.)



3.)



4.)



**Attention! Read all instructions before attaching the ProClip.**

1. a) Press the thin ends of the two enclosed gap openers into the gap between the dashboard ledge and the air vent frame to widen the gap. (The air vent frame may "pop up" a little. The distance between the gap openers has to be wider than the width of the ProClip.) b) Peel off the cover of the adhesive tape on the ProClip. Press the thin angled edge on the upper part of the ProClip into the gap between the gap openers - dont press it all the way in so the adhesive tape attaches to the ledge yet.

2. a) Remove the left gap opener and slide the ProClip to the left to desired position. b) Pull the lower part of the ProClip downwards so it hooks behind the wood grain panel. By doing this you seal the adhesive tape at the top of the ProClip.

3. a) Press upwards on the lower part of the ProClip so the angled edge goes all the way in behind the wood grain panel. b) Remove the right gap opener by the upper part of the ProClip and press down on the air vent panel so it "pops" back into place.

4. The ProClip is in place