

Manual, Assembly instruction: Brodit 853015

Center mount ONLY for wood grain panel/kevlar look. Will block display and cup holder.

1.)



2.)



3.)



4.)



Attention! Read all instructions before attaching the ProClip

1. Press the upper part of the ProClip into the gap at between the control panel and the dashboard.
2. Press the lower part of the ProClip into the gap on the control panel.
3. Press forward on the ProClip so it goes into the gaps.
4. The ProClip is in place.