

Manual, Assembly instruction: Brodit 853018

Angled mount



Attention! Read all instructions before attaching the ProClip.

1. Open the glove compartment. Loosen the screw in the upper left corner of the glove compartment. Press the thin end of the enclosed gap opener into the gap between the dashboard and the glove compartment to widen the gap. Peel off the adhesive tape covers on the ProClip.

2. Press the long right part of the ProClip into the gap above the gap opener. Pull out the gap opener.

3. Press the gap opener into the gap between the panel and the dashboard. Press the left part of the ProClip into the gap above the gap opener. Pull out the gap opener.

4. The ProClip is in place.