

Manual, Assembly instruction: Brodit 853023

Angled mount

1.)



2.)



3.)



4.)



Attention! Read all instructions before attaching the ProClip.

1. Peel off the cover of the adhesive tape on the ProClip. Place the right part of the ProClip, with adhesive tape, inside the coin compartment.

2. Press the left part of the ProClip into the gap in the left side wall of the coin compartment.

3. Pull the right part of the ProClip towards you so the right part snaps into the gap in the side wall of the coin compartment. Adjust the ProClip upwards/downwards so you feel it is in place. The ProClip is to be mounted in the exact position as shown in the pictures.

4. The ProClip is in place.