

Manual, Assembly instruction: Brodit 853025

Center mount



Attention! Read all instructions before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the dashboard ledge and the air vent panel frame to widen the gap.

2. Press the grooved edge on the lower part of the ProClip into the gap next to the gap opener. Press until you see or hear/feel it snap into place. Pull out the gap opener.

3. Press the thin end of the enclosed gap opener into the gap between the panel frame surrounding the stereo and the padded dashboard to widen the gap. Press the grooved edge on the upper part of the ProClip into the gap next to the gap opener. Note: Start by pressing forward on the upper right corner of the ProClip, and then follow through by moving your pressure over to the left corner of the ProClip. Press until you see or hear/feel it snap into place. Pull out the gap opener.

4. The ProClip is in place.