

Manual, Assembly instruction: Brodit 853027

Center mount, Low

1.)



2.)



3.)



4.)



Attention! Read all instructions before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the dashboard and the frame surrounding the control panel to widen the gap. Peel off the covers of the adhesive tape on the ProClip.
2. Press the right part of the ProClip into the gap between the stereo and the surrounding frame.
3. Press forward on the left part of the ProClip so the angled left edge hooks into the gap above the gap opener. Pull out the gap opener.
4. The ProClip is in place.