

Manual, Assembly instruction: Brodit 853029

Angled mount Will block cup holder.

1.)



2.)



3.)



Attention! Read all instructions before attaching the ProClip.

1. Press the thin end of the enclosed gap openers into the gap between the stereo/coin shelf and the surrounding frame to widen the gap. Peel off the adhesive tape covers on the ProClip. Press the left part of the ProClip into the gap between the gap openers

2. Pull out the gap openers. Press a gap opener into the gap between the dashboard and the frame surrounding the control panel. Press forward on the right part of the ProClip so the angled edge snaps into the gap above the gap opener. Pull out the gap opener.

3. The ProClip is in place.