

Manual, Assembly instruction: Brodit 853031

Angled mount, High

1.)



2.)



3.)



4.)



Attention! Read all instructions before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the dashboard and the control panel to widen the gap. Peel off the cover of the adhesive tape on the ProClip.
2. Press the left part of the ProClip, with adhesive tape, into the gap below the gap opener. Pull out the gap opener.
3. Press the gap opener into the gap in the side wall of the dashboard. Press forward on the ProClip so the angled right edge hooks into the gap above the gap opener. Pull out the gap opener.
4. The ProClip is in place.