

Manual, Assembly instruction: Brodit 853034

Angled mount

1.)



2.)



3.)



4.)



Attention! Read all instructions before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the dashboard and the frame surrounding the air vent to widen the gap. Peel off the adhesive tape covers on the ProClip.
2. Press the left part of the ProClip into the gap between the frame surrounding the control panel and the frame surrounding the air vent.
3. Press forward on the ProClip so the right edge hooks into the gap above the gap opener. Pull out the gap opener.
4. The ProClip is in place.