

Manual, Assembly instruction: Brodit 853038

Angled mount, Low

1.)



2.)



3.)



4.)



Attention! Read all instructions before attaching the ProClip.

1. Loosen the screw inside the cup holder. Peel off both adhesive tape covers on the ProClip.
2. Pull the upper edge of the cup holder upwards. Press the upper part of the ProClip into the gap. Press down the upper edge of the cup holder. Tighten the screw.
3. Hook the angled edge of the lower part of the ProClip into the gap between the upper and the lower part of the control panel.
4. The ProClip is in place.