

Manual, Assembly instruction: Brodit 853044

Center mount C2 - NOT for Elegance.

1.)



2.)



3.)



4.)



Attention! Read all instructions before attaching the ProClip. This ProClip can be placed anywhere within the width of the display.

1. Loosen the frame surrounding the display on top of the dashboard. Peel off the adhesive tape covers on the ProClip.

2. Press the long upper part of the ProClip into the gap between the display and the surrounding frame. Press downwards on the frame, in the same time press the ProClip downwards.

3. Press the thin end of the enclosed gap opener into the gap between the stereo and the surrounding dashboard to widen the gap. Press the lower part of the ProClip into the gap next to the gap opener. Pull out the gap opener.

4. The ProClip is in place.