

Manual, Assembly instruction: Brodit 853071

Angled mount

1.)



2.)



3.)



4.)



Attention! Read all instructions before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the dashboard and the frame surrounding the control panel to widen the gap. Peel off both adhesive tape covers on the ProClip.
2. Press the left part of the ProClip into the gap above the gap opener. Pull out the gap opener.
3. Press forward on the ProClip so the long right part hooks over the edge of the console.
4. The ProClip is in place.