

Manual, Assembly instruction: Brodit 853072

Center mount

1.)



2.)



3.)



4.)



Attention! Read all instructions before attaching the ProClip.

1. Peel off the cover of the adhesive tape on the ProClip. Press the lower part of the ProClip into the gap between the control panel and the dashboard surrounding the air vents.

2. Press the thin end of the enclosed gap opener into the gap between the dashboard and the speaker vent to widen the gap. Hook the upper part of the ProClip into the gap next to the gap opener. Pull out the gap opener.

3. The ProClip is in place.

4. The ProClip is in place.