

Manual, Assembly instruction: Brodit 853075

Center mount

1.)



2.)



3.)



4.)



Attention! Read all instructions before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the wood grain panel and the control panel to widen the gap. Peel off both adhesive tape covers on the ProClip.
2. Press the lower part of the ProClip into the gap next to the gap opener, to the right of the buttons on the control panel below.
3. Hook the upper part of the ProClip into the lower part of the air vent. Pull out the gap opener.
4. The ProClip is in place.