

Manual, Assembly instruction: Brodit 853076

Center mount

1.)



2.)



3.)



4.)



Attention! Read all instructions before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the ledge and the frame surrounding the display to widen the gap. Peel off the cover of the adhesive tape on the ProClip.
2. Press the angled edge of the lower part of the ProClip into the gap next to the gap opener. Pull out the gap opener.
3. Press the grooved edge of the upper part of the ProClip into the gap between the dashboard and the frame surrounding the display.
4. The ProClip is in place.