

Manual, Assembly instruction: Brodit 853080

Center mount

1.)



2.)



3.)



4.)



Attention! Read all instructions before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the control panel and the dashboard to widen the gap. Peel off the cover of the adhesive tape on the ProClip. Press the lower part of the ProClip into the gap next to the gap opener. Pull out the gap opener.
2. Press the gap opener into the gap in the dashboard, above the air vents.
3. Press the upper part of the ProClip, with adhesive tape into the gap next to the gap opener. Pull out the gap opener. Press downwards on the upper part of the ProClip so it goes all the way into the gap.
4. The ProClip is in place.