

Manual, Assembly instruction: Brodit 853082

Angled mount

1.)



2.)



3.)



4.)



Attention! Read all instructions before attaching the ProClip. This ProClip consists of two parts. Part 1. Attaching part (the smallest part) Part 2. ProClip face plate

1. Press the thin end of the enclosed gap openers into the gap between the control panel and the dashboard to widen the gap. Place the gap openers about 10 cm apart.

2. Peel off the cover of the adhesive tape on Part 1. Press Part 1 into the gap, between the gap openers. Press Part 1 to the right, away from the steering wheel, so the angled edge hooks behind the control panel and the adhesive attaches to the dashboard. Pull out the gap openers.

3. Open up the predrilled holes in Part 2 with a screwdriver (Philips). Peel off the cover of the adhesive tape on Part 2. Place Part 2 over Part 1 so the adhesive tape is on the left and the holes match. Screw Part 2 onto Part 1 by using the enclosed screws. NOTE! Screw the screws straight into Part 1, in the same angle as Part 1.

4. The ProClip is in place.