

Manual, Assembly instruction: Brodit 853083

Center mount, High

1.)



2.)



3.)



4.)



Attention! Read all instructions before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap in the dashboard above the air vent to widen the gap. Peel off the cover of the adhesive tape on the ProClip. Press the angled edge of the upper part of the ProClip into the gap next to the gap opener.

2. Hook the lower part of the ProClip, with adhesive tape, under the frame surrounding the air vent. Pull out the gap opener.

3. The ProClip is in place.

4. The ProClip is in place.