

Manual, Assembly instruction: Brodit 853086

Center mount

1.)



2.)



3.)



4.)



Attention! Read all instructions before attaching the ProClip.

1. Press the thin end of the enclosed gap opener upwards into the gap between the control panel and the frame surrounding the air vent to widen the gap (the air vent frame will then bend outwards). Peel off the cover of the adhesive tape on the ProClip. Press the grooved edge of the lower part of the ProClip into the gap next to the gap opener.

2. Slide the ProClip leftwards, towards the steering wheel. Pull out the gap opener.

3. Hook the angled edge of the upper part of the ProClip into the gap between the dashboard and the frame surrounding the air vent. Press downwards on the upper part of the ProClip so it goes into the gap.

4. The ProClip is in place.