

## Manual, Assembly instruction: Brodit 853087

Angled mount, High

1.)



2.)



3.)



4.)



**Please read all of the instructions and look at the pictures before attaching the ProClip.**

1. Press the thin end of the enclosed gap opener upwards into the gap between the air vent frame and the stereo, to widen the gap. (the air vent frame will then bend outwards). Peel off the cover of the adhesive tape on the ProClip.
2. Hook the angled edge on the upper part of the ProClip into the gap between the dashboard and the frame surrounding the air vent. Press down on top of the ProClip so it goes into the gap.
3. Press the grooved on the lower part of the ProClip into the gap next to the gap opener. Press until you see or hear/feel it snaps into place. Pull out the gap opener.
4. The ProClip is in place.