

Manual, Assembly instruction: Brodit 853088

Angled mount NOT for models with cup holder.



Attention! Read all instructions before attaching the ProClip.

1. Open the glove compartment. Peel off the adhesive tape covers on the ProClip. Press the angled edge of the long right part of the ProClip into the gap between the glove compartment and the dashboard.
2. Press the left part of the ProClip towards the steering wheel so the angled edge hooks behind the glove compartment.
3. Hook the left part of the ProClip into the gap between the control panel and the surrounding frame.
4. The ProClip is in place.