

Manual, Assembly instruction: Brodit 853090

Angled mount, High

1.)



2.)



3.)



4.)



Attention! Read all instructions before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the dashboard and the frame surrounding the air vent to widen the gap. Peel off the cover of the adhesive tape on the ProClip.
2. Press the lower part of the ProClip, with adhesive tape, into the gap between the control panel and the frame surrounding the air vent.
3. Hook the angled edge of the upper part of the ProClip into the gap next to the gap opener. Pull out the gap opener.
4. The ProClip is in place.