

Manual, Assembly instruction: Brodit 853092

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the cover of the adhesive tape on the ProClip. Press the upper part of the ProClip towards the console padding and at the same time: press the grooved edge on the upper part into the gap between the console edge and the climate control panel.
2. Press firmly forward on the mid/lower part of the ProClip so the rest of the grooved edge goes onto the gap. Press until you see or hear/feel it snaps into place.
3. Press forward on the right side of the ProClip so the angled edge snaps into the gap in the console sidewall. Press firmly forward until you see or hear/feel it snaps into place. 4. The ProClip is in place.