

Manual, Assembly instruction: Brodit 853093

Angled mount



Attention: Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap in the center console sidewall to widen it. Peel off the cover of the adhesive tape on the ProClip.

2. Press the angled edge on the left side of the ProClip into the gap between the climate control panel and the surrounding panel frame.

3. Press forward on the right side of the ProClip so the angled edge snaps into the gap above the gap opener. Pull out the gap opener.

4. The ProClip in place.