

## Manual, Assembly instruction: Brodit 853097

Angled mount

1.)



2.)



3.)



4.)



**Attention: Please read all of the instructions and look at the pictures before attaching the ProClip.**

1. Press the thin end of the enclosed gap opener into the gap between the center console sidewall and the center console panel, to widen it. Peel off the cover of the adhesive tape on the ProClip. Hook the angled edge on the right side of the ProClip into the gap next to the gap opener.

2. Pull out the gap opener and press it into the gap between the center console panel and the center console edge, to widen the gap.

3. Press the ProClip firmly to the left, towards the steering wheel, so the angled edge on the left side of the ProClip snaps over the center console edge and into the gap. Pull out the gap opener.

4. The ProClip is in place.