

Manual, Assembly instruction: Brodit 853111

Center mount

1.)



2.)



3.)



4.)



Attention: Please read all of the instructions and look at the pictures before attaching the ProClip.

NOTE: This ProClip can be attached to the dashboard as shown in the above overview picture. In the pictures the dashboard may look slightly different from yours i.e. different stereo, buttons for the On Star System, Panel frame etc. but this has been taken into consideration and the ProClip will fit your dashboard. Just follow the directions below.

1. Peel off the cover of the adhesive tape on the ProClip. Press/hook the angled edge on the right side of the ProClip into the gap between the air vent and the surrounding panel frame.

2. Place your hand on the right side of the faceplate and your thumb on to the left side of the faceplate. At the same time: Press the ProClip firmly to the right, towards the steering wheel, and forward, towards the stereo, so the angled edge on the left side of the ProClip snaps into the gap between the stereo and the surrounding panel frame.

3. The ProClip is in place.

4. The ProClip is in place.