

Manual, Assembly instruction: Brodit 853135

Angled mount

1.)



2.)



3.)



4.)



Attention! Read all instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the dashboard and the frame surrounding the control panel to widen the gap. Peel off the adhesive tape cover on the ProClip.
2. Press the curved edge on the left part of the ProClip into the gap below the gap opener.
3. Press forwards on the right side of the ProClip so the grooved edge on the right part of the ProClip snaps into place in the gap between the dashboard surrounding the control panel and the dashboard surrounding the glove compartment. Pull out the gap opener.
4. The ProClip is in place.