

Manual, Assembly instruction: Brodit 853136

Angled mount

1.)



2.)



3.)



4.)



Attention! Read all instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the panel surrounding the air vent and the dashboard to widen the gap. Peel off both adhesive tape covers on the ProClip.

2. Press the angled edge of the lower part of the ProClip into the gap next to the gap opener. Pull out the gap opener.

3. Pull the upper part of the ProClip upwards so the upper edge of the ProClip hooks over the edge of the coin shelf.

4. The ProClip is in place.