

Manual, Assembly instruction: Brodit 853137

Center mount

1.)



2.)



3.)



4.)



Attention! Read all instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the air vent frame and the dashboard to widen the gap. Peel off the cover of the adhesive tape on the ProClip. Press the grooved edge on the upper part of the ProClip into the gap next to the gap opener. Pull out the gap opener.
2. Adjust the ProClip sideways in the gap until you feel or see/hear it snaps into place.
3. Press the thin end of the gap opener into the gap between the stereo and the surrounding panel frame to widen the gap. Press the lower part of the ProClip, with adhesive tape, into the gap next to the gap opener. Pull out the gap opener.
4. The ProClip is in place.