

Manual, Assembly instruction: Brodit 853138

Angled mount, High ONLY for models with cup holder.

1.)



2.)



3.)



4.)



Attention! Read all instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the stereo and the surrounding panel frame to widen the gap. Peel off the cover of the adhesive tape on the ProClip.
2. Press the lower part of the ProClip, with adhesive tape, into the gap next to the gap opener. Pull out the gap opener.
3. Press the grooved edge on the upper part of the ProClip into the gap between the air vent panel frame and the dashboard. Press firmly forward until you see or hear/feel it snaps into place.
4. The ProClip is in place.