

Manual, Assembly instruction: Brodit 853140

Angled mount



Attention! Read all instructions and look at the pictures before attaching the ProClip. This ProClip consists of two parts. Part 1. Attaching part (the smallest part) Part 2. ProClip face plate

1. Press the thin ends of the enclosed gap openers into the gap between the frame surrounding the controlpanel and the dashboard to widen the gap. Place the gap openers approx. 10 cm apart, one aligned with the upper part of the stereo and one aligned with the lower part of the stereo. Peel off the adhesive tape cover on Part 1. Press the angled edge of Part 1 into the gap between the gap openers.

2. Press Part 1 rightwards, away from the steering wheel, so the angled edge hooks behind the control panel frame and the adhesive tape attaches. Pull out the gap openers.

3. Open up the predrilled holes in Part 2 with a screwdriver (Philips). Peel off the adhesive tape cover on Part 2. Place Part 2 onto Part 1 so the holes match. Screw Part 2 onto Part 1 with the enclosed screw. **NOTE!** Screw the screws straight into Part 1, in the same angle as Part 1.

4. The ProClip is in place.