

Manual, Assembly instruction: Brodit 853143

Center mount

1.)



2.)



3.)



4.)



Attention! Read all instructions and look at the pictures before attaching the ProClip.

1. Peel off the adhesive tape cover on the ProClip. Press the curved edge of the lower part of the ProClip into the gap in the control panel below the air vent.

2. Press forward on the lower part of the ProClip, in the same time: pull the upper part of the ProClip upwards so the curved edge hooks into the gap.

3. Press the thin end of the enclosed gap opener into the gap in the control panel above the air vent to widen the gap. Press the upper part of the ProClip (with adhesive tape) into the gap next to the gap opener. Pull out the gap opener.

4. The ProClip is in place.