

Manual, Assembly instruction: Brodit 853144

Angled mount

1.)



2.)



3.)



4.)



Attention! Read all instructions and look at the pictures before attaching the ProClip. This ProClip consists of two parts. Part 1: Attaching part. (The smallest part) Part 2: ProClip face plate

1. Press the thin end of the enclosed gap opener into the gap between the control panel and the surrounding the frame to widen the gap. Peel off the cover of the adhesive tape on Part 1. Press the angled edge into the gap above the gap opener.

2. Press Part 1 rightwards, away from the steering wheel, so the angled edge hooks behind the control panel and the adhesive tape attaches to the surrounding frame. Pull out the gap opener.

3. Open up the predrilled holes in Part 2 with a screwdriver (Philips). Peel off the cover of the adhesive tape. Place Part 2 onto Part 1 so the holes match and the adhesive tape is to the left. Screw Part 2 onto Part 1 with the enclosed screws. NOTE! Screw straight into Part 1, in the same angle as Part 1.

4. The ProClip is in place.